## PYRITE+ MEC172x Modular EC Card


Mates with Intel RVP TigerLake/Alder Lake Platforms


**BLOCK DIAGRAM** 


| Description                                    | Sheet |
|--|-------|
| Title Page                                     | 1     |
| MEC1723  | 2     |
| EC Connector, SPI Flash                        | 3     |
| H1 Controller, Keyboard Scan, Trace FIFO, JTAG | 4     |
| Servo Header                                   | 5     |
| C2D2 Muxing, UART Switches                     | 6     |
| TBD  | 7     |
| TBD  | 8     |
| TBD  | 9     |
| TBD  | 10    |
| TBD  | 11    |
| TBD  | 12    |
| TBD  | 13    |
| TBD  | 14    |


**Revision History** 


Rev 1.0:














## C2D2 TO PCH SPI STUFFING OPTION





C2D2 HEADER

## **UART SELECTION SWITCH CIRCUIT**



| s.NO. | C2D2 MUX INPUT                  | C2D2 MUX OUTPUT        | NC/NO | FUNCTION |  |
|-------|---------------------------------|------------------------|-------|----------|--|
| 1     | CODO CON HART EC TV DRG BY CDA  | UART_EC_TX_DBG_RX_SDA  | NC1   | EC       |  |
| 1     | C2D2_CSN_UART_EC_TX_DBG_RX_SDA  | AP_SPI_FLASH_CS_L      | NO1   | SPI ROM  |  |
| 2     | C2D2 CIV HAPT DBG TV EC BY SCI  | UART_DBG_TX_EC_RX_SCL  | NC2   | EC       |  |
|       | C2D2_CLK_UART_DBG_TX_EC_RX_SCL  | AP_SPI_FLASH_CLK       | NO2   | SPI ROM  |  |
| 3     | C2D2_MISO_UART_H1_TX_DBG_RX     | C2D2_UART_H1_TX_DBG_RX |       | H1       |  |
| 3     |                                 | AP_SPI_FLASH_MISO_R    | NO3   | SPI ROM  |  |
|       | C2D2_MOSI_UART_DBG_TX_H1_RX     | C2D2_UART_DBG_TX_H1_RX | NC4   | H1       |  |
| 4     |                                 | AP_SPI_FLASH_MOSI      | NO4   | SPI ROM  |  |
| 5     | C2D2 HOLDN ECVEEL HT DWEETH OD  | MECH_PWR_BTN_IN_ODL    | NC5   | PWR BTN  |  |
| 5 (   | C2D2_HOLDN_ECVREF_H1_PWRBTN_ODL | AP_SPI_FLASH_HOLD_L    | NO5   | SPI ROM  |  |
| 6     | CADA VIDEE 114 BCT ODI          | RESET_H1_ODL           | NC6   | H1       |  |
|       | C2D2_VREF_H1_RST_ODL            | PP3300_AP_FLASH        | N06   | POWER    |  |
| 7     | GROUND                          | GROUND                 |       | GND      |  |
| 8     | C2D2 MILY HART OD               | MUX SWITCH             | IN1   | SEL1     |  |
| 8     | C2D2_MUX_UART_ODL               | WIOX SWITCH            | IN2   | SEL2     |  |

| Switch     | Switch<br>Position | Servo Config |          |          |           |          |  |  |
|------------|--------------------|--------------|----------|----------|-----------|----------|--|--|
|            |                    | EC UART      |          | SOC UART | ICHLIADT  | H1 UART  |  |  |
|            |                    | Mica EC      | RVP EC   | 30C UART | ISH UART  | HI UAKI  |  |  |
| S6         | On                 |              |          |          |           |          |  |  |
|            | Off                |              |          |          |           |          |  |  |
| S5         | On                 |              |          |          | 1-8, 2- 7 | 3-6, 4-5 |  |  |
|            | Off                |              |          |          | 3-X, 4-X  | 1-X, 2-X |  |  |
| <b>S</b> 4 | On                 | 1-8, 2-7     | 3-6, 4-5 |          | 20        |          |  |  |
|            | Off                | 3-X, 4-X     | 1-X, 2-X |          |           |          |  |  |
| <b>S</b> 3 | On                 |              | 300      |          |           |          |  |  |
|            | Off                |              |          |          |           |          |  |  |

|            | Switch<br>Position | C2D2 Config |          |          |          |          |           |  |
|------------|--------------------|-------------|----------|----------|----------|----------|-----------|--|
| Switch     |                    | EC UART     |          | FCHART   | COCHART  | ICHLIADT | III IIADT |  |
|            |                    | Mica EC     | RVP EC   | EC UART  | SOC UART | ISH UART | H1 UART   |  |
| S6         | On                 |             |          |          | 1-8, 2-7 |          | 3-6, 4-5  |  |
|            | Off                |             | 50.00    |          | 3-X, 4-X |          | 1-X, 2-X  |  |
| <b>S</b> 5 | On                 |             | A. 2.5   |          |          |          |           |  |
|            | Off                |             |          |          |          |          |           |  |
| <b>S4</b>  | On                 | 1-8, 2-7    | 3-6, 4-5 |          |          |          |           |  |
| 34         | Off                | 3-X, 4-X    | 1-X, 2-X |          |          |          |           |  |
| : S3       | On                 |             |          | 1-8, 2-7 |          | 3-6, 4-5 |           |  |
|            | Off                |             |          | 3-X, 4-X |          | 1-X, 2-X |           |  |

| MICROCHIP Microchip Technology Inc. www.microchip.com |                                     |                  |  |          |           |  |  |  |
|---|-------------------------------------|------------------|--|----------|-----------|--|--|--|
| EVB N   | EVB Number: TBD                     |                  |  |          |           |  |  |  |
| Page 1  | Page Title: MEC1723 Modular EC Card |                  |  |          |           |  |  |  |
| Size:   | Engineer:                           | Assembly Number: |  | PCB Rev: | Sch. Rev: |  |  |  |
| C   | T.T.                                | 6930             |  | A        | 1.0       |  |  |  |
| Date:   | Monday, Marci                       | 29, 2021         |  | Sheet 6  | of 6      |  |  |  |